CF-12E中英文说明书 （骑马钉）
材质：105g哑粉纸 尺寸：60x62mm 印刷：4C+PANTONE COOL GRAY 8 C

inFace 声波洁面仪 II

使用说明书

inFace声波洁面仪 II

欢迎使用inFace

inFace声波洁面仪 II 由深圳圆易科技有限公司自主研发制造，深圳圆易科技有限公司是属于深圳市美容智能有限公司，公司自成立以来，一直以产品的高性能、功能性及安全性为设计核心理念，以打造科技智美时产品为宗旨，努力做到，不断创新。

inFace声波洁面仪 II

产品功能

深层清洁 / 去除角质 / 净透毛孔

※使用产品前请仔细阅读本说明书，并妥善保存

产品注意

注意事项 ····· 01
产品结构 ····· 02
产品参数 ····· 03
使用说明 ····· 04
充电须知 ····· 04
产品使用 ····· 05
产品中有害物质的名称及含量 ····· 06
常见问题 ····· 07
环境保护 ····· 08
廖物处理 ····· 09
售后保修须知 ····· 10
合格证 ····· 11
保修卡 ····· 11
售后联系方式 ····· 12

注意事项

请仔细阅读并理解以下安全指南：

1. 请勿将产品放置在儿童可及的位置或靠近热源，如加热器或炉灶。
2. 切勿在有任何损伤的面，请在使用本产品之前先咨询医生。
3. 不适用于头皮或身体其他部位。
4. 请勿将产品浸入水中或暴露在任何液体中。
5. 请勿使用非本品牌的充电装置或电池。
6. 请勿在潮湿的环境中使用。
7. 请勿将产品暴露在极端温度下，例如在车辆或阳光直射下。
8. 请勿将产品放置在儿童可及的位置或靠近热源，如加热器或炉灶。
9. 请勿在有任何损伤的面，请在使用本产品之前先咨询医生。
10. 请勿在潮湿的环境中使用。
11. 请勿将产品暴露在极端温度下，例如在车辆或阳光直射下。
12. 请勿将产品放置在儿童可及的位置或靠近热源，如加热器或炉灶。
13. 请勿在有任何损伤的面，请在使用本产品之前先咨询医生。

产品结构

打开包装盒，可得套件：

1. inFace声波洁面仪 x1
2. 数据线 x1
3. 使用说明书 x1
4. 硅胶洁面刷头 x1

（如有缺少一个或多个上述配件，请联系当地售后客服中心）



02

产品参数

产品名称：inFace声波洁面仪 II
产品型号：CF-12E
电池规格：1*18650
电池容量：2000mAh
充电时间：约3.5小时
工作温度范围：0°C~40°C
产品尺寸：60.5*60.5*102mm
产品净重：约140g
电池容量：1000mAh
输入电压：5V⎓
输入功率：2W
使用寿命：3.7V⎓
额定功率：2.5W

注：本说明书所示产品图片及配件仅供参考，以实物为准。

03

使用说明

1. 关机状态下，长按“电源 / 模式键”1.5 秒，电源开启，LED 灯亮起，默认为“清洁 / 舒缓”，可以在下一节 1 分钟“清洁 / 舒缓”切换。
2. 每个档位模式工作 30 秒后设备自动关机。
3. 在第二节时关下，长按“电源 / 模式键”1.5 秒，设备关机。
4. 在每档下可使用，按键静音关机。

04

充电须知

1. 仅在充电之前，请检查充电线和 USB 接口是否有损坏。
2. 请选用标准的 DC 5V/1A 适配器进行充电。
3. 请将提供的充电线连接至设备的充电接口，并将适配器插入电源插座。
4. 充电时，LED 指示灯将亮起，表示设备正在充电。
5. 充电完成后，LED 指示灯将熄灭，表示设备已充满电。
6. 充电时间大约为 3.5 小时，具体时间可能因电池容量和剩余电量而有所不同。
7. 请勿在充电过程中使用设备，以确保安全。
8. 充电完成后，请及时拔下充电线，以避免过度充电。

05

产品中有害物质的名称及含量

部件名称	有害物质					
	铅 (Pb)	汞 (Hg)	镉 (Cd)	六价铬 (Cr(VI))	多溴联苯 (PBB)	多溴二苯醚 (PBDE)
塑料外壳	○	○	○	○	○	○
硅胶刷头	○	○	○	○	○	○
电池	○	○	○	○	○	○
电路板	○	○	○	○	○	○
充电线	○	○	○	○	○	○

○：表示该有害物质在该部件所有均质材料中的含量均在 GB/T 26572 规定的限量要求以下。

×：表示该部件的至少一种均质材料中的有害物质含量超出 GB/T 26572 规定的限量要求。

注：本表格所列出的部件为本产品的主要组成部件。

06

产品中有害物质或元素的名称及含量

依照法规对产品的环保使用期限为 10 年，在符合正常使用情况下，产品中含有的有害物质不会发生泄漏或变异，从而不会对环境造成严重污染或者对人身、财产造成严重损害。此期限不适用于电池或其他在产品中有更短声明期限的部件。

07

廖型说明

使用时需注意回收，请参照下列要求：

1. 请勿将产品丢弃在垃圾箱中。
2. 请将产品交给当地的回收站点处理。
3. 请勿随意冲洗、拆卸或焚烧该产品。
4. 请将废弃的电池与产品分开，并按当地要求处理。

08

Q：多久用一次？
A：每天使用两次，每次一分钟即可达到最佳的清洁效果，避免使用过度或过长时间，否则可能会刺激皮肤。

Q：建议搭配什么清洁产品使用？
A：为了获得最佳效果，建议使用温和的洁面凝胶或产品。可将其涂抹在湿润的面部或直接在刷头上使用。

Q：如何清理硅胶刷头？
A：用水温不宜过高，请用手在温和节水模式下清洗，避免使用含有磨砂颗粒的清洁剂，以免损伤刷头。

Q：刷头需要定期更换吗？
A：是的，建议每 3 个月更换一次刷头，以确保最佳清洁效果。

Q：可以在洗澡时使用吗？
A：不建议在洗澡时使用，以避免水进入设备内部，导致故障。

Q：如何充电？
A：请使用随附的 USB 充电线将设备连接到电源适配器。充电时，LED 指示灯将亮起，充满后将熄灭。

09

环境保护

1. 本产品所包装材料均为室外都是用可回收利用的材料制造。
2. 请直接将此可回收的回收利用标志贴在产品的包装上。

废物处理

仅用户直接使用后将电池拆上的成品和，请交给产品使用者将电池拆下，不能被当作一般家庭废物处理，请交给当地的回收站点或者供应商进行回收处理，以保护环境和人类健康。电池回收是保护环境、节约资源的一项重要措施，请积极参与电池回收，共同为环境保护做出贡献。

售后保修须知

1. 在保修期内，如产品出现非人为因素造成的故障，请联系我们的售后服务部门，我们将为您提供免费的维修或更换服务。
2. 保修期限为自购买日期起一年。
3. 保修范围不包括因滥用、疏忽、意外损坏等情况。
4. 保修期内，如产品出现非人为因素造成的故障，请联系我们的售后服务部门，我们将为您提供免费的维修或更换服务。
5. 保修期限为自购买日期起一年。

10

合格证



11

保修卡

11

售后联系方式

电话：400-027-6388
服务微信号：cnjoyoo-cn
工作时间：周一至周六 9:00-18:00（节假日休息）

公司信息：深圳市米谷智能有限公司
地址：深圳市宝安区西乡街道固戍社区翻身路产业园16栋3层
邮箱：service@migoosmart.com
邮编：518000
官方网站：www.migoosmart.com





12

inFace Sonic Facial Device II

User Manual

Welcome to Use inFace

inFace Sonic Facial Device Ⅱ is independently developed and manufactured by Shenzhen inFace Technology Co., Ltd. inFace Technology is a Migoo Management Co., Ltd. Since the company was founded, it has been designed the core concepts of practicality, user-friendliness and safety, aiming to create products with technology and intellectual, and striving to explore and innovate.

inFace Sonic Facial Device Ⅰ

Functions of the Product

Deep Cleaning / Remove Dead Skin / Clean Pores

※Please read this manual carefully before using the product and keep it properly.

Product List

Product Details ····· 15
Product Parameters ····· 16
Instructions ····· 17
Charging Instructions ····· 18
Cleaning and Maintenance ····· 20
Q&A ····· 21
Environmental Protection ····· 23
Warranty Terms ····· 24
Warranty Card ····· 24
After-sales Contact Information ····· 27

Precautions

Please read and follow the following safety guidelines:

1. If you have acne, wounds, or after surgery, please follow your doctor's advice and use it with caution.
2. Protective skin is recommended to use at the lowest level.
3. Pregnant women please consult a doctor before use.
4. Do not allow children to use this product, please place this product out of the reach of children.
5. It is recommended that users who undergo facial surgery or plastic surgery to consult the guidance of a physician.
6. If you have any skin problems, please consult your doctor before using this product.

14

7. The cleaning brush head is recommended to be replaced every 3 months.
8. It is not recommended to soak this product in water for a long time to prevent some performance from being affected.
9. After use, please turn off the power and clean the product in time.
10. Do not use while charging.
11. Do not use organic solvents such as alcohol, gasoline, and thinner to clean this product.
12. If you feel unwell during use, please stop using it immediately.
13. If the product is damaged, please stop using it.

15

Product Details

Open the box and you will see

1. inFace Sonic Facial Device Ⅱ x1
2. Brush Head x2
3. USB Charging Cable x1
4. User Manual and Warranty Card x1

(If there are the above accessories is missing, please contact our after-sales customer service center.)



16

Product Parameters

Product Name: inFace Sonic Facial Device Ⅰ
Model: CF-12E
Battery Capacity: 400mAh
Product Size: 48.5*48.5*102mm
Net Weight: About 140g
Charging Time: About 1.5 hours
Continuous Working Time: About 90 min
Working Temperature Range: 0°C~40°C

Input Voltage: 5V⎓
Input Power: 2W
Battery Voltage: 3.7V
Rated Power: 2.5W

Note: The product pictures and the description of the relevant functions shown in this manual, as well as the explanations of some nouns, can only be used as a reference. Users shall bear the actual objects. In view of the consistent policy of continuously improving inFace products, we reserve the right to change the specifications of products without further notice.

17

Instructions

1. In the powered-off state, long press the "ON / OFF Button / Level Button" for 1.5 seconds, the power is turned on, and enters the first level by default, short press the "ON / OFF Button / Level Button", the level switch cyclically between "level 1~level 3~level 2".
2. The device will automatically shut down after 90 seconds of working in each level mode.
3. In any working state, long press the "ON / OFF Button / Level Button" for 1.5 seconds, the device will shut down.
4. It cannot be used while charging, and the button operation is invalid.

Charging Instructions

5. It is recommended to use foam-rich cleansing products. If you use a non-squeezing foam product, you can use the non-activated sonic facial device to gently rub the cleansing cream / powder / gel to form a rich foam, and then activate the sonic facial device to use.
6. Please do not disassemble or repair this device by yourself. For maintenance matters, please contact the after-sales service provider of the device.

Q&A

If you find a problem during use, please refer to the table below to troubleshoot the abnormality. If the problem cannot be solved, please contact after-sales service.

18

Q: The device will automatically shut down after 90 seconds of use?
A: It is not a product quality problem. This device comes with a 90-second intelligent timer protection function. After 90 seconds of continuous use, the device will automatically shut down to avoid excessive cleaning. It can be used if it needs to be operated and restarted.

Q: During use, the irritation caused by sonic vibration makes the skin uncomfortable.
A: Please adjust the low level appropriately, and it is not recommended to use the high level for sensitive skin.

Q: How often do you use it ?
A: It can be used twice a day.The frequency of use can be adjusted according to the skin condition, and each use should not exceed 3 minutes. If you have makeup, it is recommended to clean it after use.

19

Q: What cleansing products are recommended to be used with ?
A: It is recommended to use foam-rich cleansing products. If you use a non-squeezing foam product, you can use the non-activated sonic facial device to gently rub the cleansing cream / powder / gel to form a rich foam, and then activate the sonic facial device to use.

Q: Can the device be used in the shower?
A: The brush head can be washed, put the product upside down on the base and place it in a ventilated place to dry.

2. Please store the device in the normal drying room.
3. Please do not disassemble or repair this device by yourself. For maintenance matters, please contact the after-sales service provider of the device.

20

Environmental Protection

1. The packaging materials of this product are all made of recyclable materials. Please put the recyclable logo on the packaging.

Waste Treatment

This label on this product or on the users' manual or on the package indicates that the product cannot be disposed of as general household waste at the end of its life cycle. Please contact the local government for recycling according to the classification of the waste. Please remove the battery from the device before discarding the appliance, and must keep the machine power off when removing the battery, the battery must be safely disposed.

21

Warranties Protection and Service

We provide a one-year warranty for products service standard. The warranty period starts from the date of purchase.

2.To apply for warranty, the product and the proof (purchase invoice) that can prove the purchase date must be presented to the dealer.

3.The following conditions are not covered by the warranty:

4.Damage caused by improper use, for example: using the wrong power supply, inserting the product into an unsuitable socket, excessive force, etc.

5.Product aging and wear caused by normal use.

22

6.Use the product in the wrong way, for example: using the product for purposes other than those described in the manual.

7.Damage caused by repair or attempted repair by anyone who is not an authorized service technician.

8.Damage caused by force majeure, for example: fire, flood, lightning, etc.

9.Damage caused by contact with liquid, water or moisture, unless this is an expected result of using the product.

10.Damage caused by exposure to extreme temperatures or direct sunlight.

11.Damage caused by failure to follow the instructions for cleaning and maintenance.

12.Damage caused by the use of accessories or spare parts not approved by the manufacturer.

13.Damage caused by accidental impact or dropping of the product.

14.Damage caused by pests or rodents.

15.Damage caused by chemical exposure, such as cleaning agents or solvents, unless specifically recommended for use with the product.

16.Damage caused by failure to maintain the product as instructed, for example: not cleaning the brush head regularly.

23

After-sales Contact Information

Tel: 0086-400-027-6388
Service Wechat Account: migoosmart
Working time: 9:00-18:00 from Monday to Saturday (China time, day off on holidays and weekend)

Company Information: Shenzhen Migoosmart Co., Ltd.
Address: Rm.807, Building 16B, Junxiang 1/F Intelligent Manufacturing Industrial Park, Gushu Community, Xixiang Sub-District, Bao'an District, Shenzhen, China
Email: service@migoosmart.com
Post Code: 518000
Official Website: www.migoosmart.com

If The final interpretation right belongs to Shenzhen Migoosmart Co., Ltd.

24





26





27