Argus Series B440

Telecamera Pan-Tilt 4K da 8 MP alimentata a energia solare/batteria con rilevamento intelligente, visione notturna a colori e WiFi Dual-Band 5/2,4 GHz

- 4K 8MP Ultra HD
- Panoramica a 355° e inclinazione a 140
- Visione notturna a colori

Specifications

Video & Audio	
Tipo Sensore	1/2.7" CMOS Sensor
Risoluzione Video	3840 x 2160 (8.0 Megapixels)@15fps
Compressione Video	H.265
Angolo di Visione	Fixed Lens, Horizontal: 90°, Vertical: 47°, Diagonal: 110°
Visione notturna a infrarossi	Up to 10 Meters (33ft) (LED: 2pcs/1.2W/ 850nm)
Visuale notturna a colori	Spotlight: 2pcs/2.4W/6500K
Audio	Two-Way Audio
Rilevamento PIR & Avvisi	
Allarme intelligente	PIR Detection/Human Detection/ Vehicle Detection/Pet Detection
Distanza di Rilevamento PIR	Adjustable up to 10m (33 ft)
Angolo di Rilevamento PIR	120° Horizontal

Avvisi Audio	Customized Verbal Alerts
Registrazione	Motion-Triggered Recording
Altri Avvisi	Instant Email Alerts & Push Notifications
Pan & Tilt	
Panoramica e inclinazione	Pan: 355°, Tilt: 140°
Punti Preset	Supports 1 guard position & up to 32 preset positions
Wireless	
Frequenza operativa	2.4GHz/5GHz
Standard wireless	IEEE 802.11a/b/g/n
Standard Wireless	WPA-PSK/WPA2-PSK
Video & Audio	
Batteria	21.6Wh rechargeable battery (Battery life varies based on settings, usage & temperature)
Alimentazione Solare	Reolink Solar Panel 2
Alimentazione DC	USB Type-C Port
Archiviazione	
Archiviazione Locale	Supports up to 128GB microSD card
Archiviazione Cloud	Supports Reolink Cloud (available in selected countries)
Casa intelligente	
Smart Home	Google Assistant, Alexa
Ambiente di Esercizio	
Temperatura di Esercizio	-10 to 55° C (14° to 131° F)
Impermeabilità	IP64
Dimensione & Peso	
Dimensione	Φ98 x 122mm
Peso (con la batteria)	481g

Garanzia	
Garanzia Limitata	2-year limited warranty. For support, visit https://support.reolink.com/hc/en-us/

Gallery & Specs



1. Speaker
2. IR LED
3. Spotlight
4. Daylight sensor
5. Lens
6. Status LED
7. Built-in PIR sensor
8. Built-in Mic



1. Antenna
2. USB-C Port
3. Power Button
4. microSD Card Slot
5. Reset Hole